


POLSPOTTEN

**instruction manual**



**polspotten.nl**  
**global-from-holland**

---

## **Zig Zag Stool Outdoor**

designed by **polspotten studio**

**510-070-series**

“ Thank you for choosing a pols potten product.  
To ensure safe and satisfactory use of this product,  
please carefully read the below instructions beforehand.”

## **care instructions**

---

### **how to avoid scratches?**

- Gently wipe the dust from the surface with a clean and soft cloth.
- Clean the surface with lukewarm water and a soft, dust free cloth.  
Do not use a cream surface cleaner.

### **caution!**

- Hot consumptions (temperatures above 50 degrees Celsius), for example mugs, cups and plates effect the surface.  
The use of coasters is advised.
- Keep out of direct sunlight and away from heat sources.

## **safety note**

---

- Always lift the furniture when moving it. Please take care when handling or moving the furniture as careless handling may cause damage or injury.
- Never tilt the furniture. Ensure the furniture is always placed firmly on the ground.
- Do not stand, climb or jump on the furniture.
- Please keep these instructions for future reference.
- 120 kg max. load.